


USE Browser(IE chrome) Login Dahua NVR,
Click Settings-"Remote Device"

The screenshot shows the 'Camera' (摄像头) settings page in a Dahua NVR web interface. The left sidebar contains a menu with options like 'Remote Device' (远程设备), 'Camera' (摄像头), 'Encoding Settings' (编码设置), 'Channel Name' (通道名称), 'IPC Upgrade' (IPC升级), 'Network' (网络), 'Events' (事件), 'Storage' (存储), and 'System Settings' (系统设置). The main area is titled '摄像头' and features a table with columns for IP address, port, device name, manufacturer, and type. Below the table are buttons for 'Device Search' (设备搜索), 'Add' (添加), and a 'Display Filter' (显示筛选) dropdown set to 'None' (无). At the bottom, there are buttons for 'Delete' (删除), 'Manual Add' (手动添加), and 'Refresh' (刷新). A green arrow points to the 'Manual Add' button, which is also enclosed in a blue box.

IP地址	端口	设备名称	厂商	类型	MAC地址

通道	修改	删除	连接状态	IP地址	端口	设备名称	远程通道号	厂商	通道名称
<input type="checkbox"/> 1				192.168.0.15	5070		1	GB28181	
<input type="checkbox"/> 2				192.168.0.15	5070		2	GB28181	
<input type="checkbox"/> 3				192.168.0.15	5070		3	GB28181	
<input type="checkbox"/> 4				192.168.0.15	5070		4	GB28181	

Click -> "Manully ADD"



Main Stream rtsp://192.168.1.10:554/user=admin&password=&channel=1&stream=0.sdp?real_stream

Sub Stream rtsp://192.168.1.10:554/user=admin&password=&channel=1&stream=1.sdp?real_stream

rtsp:// 192.168.1.10:554/user=admin&password=&channel=1&stream=0.sdp?real_stream

↑
encoder
IP address

↑
username

↑
password

↑
channel
1
2
3
4

↑
Stream
0 Main stream
1 Sub stream